




TEMPLATE RIB No. 1




SPAR CAP ASSY - REAR SPAR  
FULL SCALE MAKE 2 MATERIAL: 5/16" SQ. SPRUCE




TEMPLATE RIB No. 2




SPAR CAP ASSY - FRONT SPAR  
FULL SCALE MATERIAL: 1/4" SQ. SPRUCE MAKE 2




TEMPLATE RIB No. 3




DETAIL - REAR SPAR WEB SCALE = 1/4  
MATERIAL: 1/32" PLYWOOD MAKE 1




TEMPLATE RIB No. 4




DETAIL - FRONT SPAR WEB 1/4 SCALE  
MATERIAL: 1/32" PLYWOOD MAKE 1




TEMPLATE RIB No. 5



TEMPLATES  
TRAILING EDGE FORMERS  
FOR VERTICAL FIN  
USED ON SHEET No. 2  
MATERIAL: 1/4" PLYWOOD



TEMPLATE MAKE 1  
FORWARD SPAR  
REINFORCEMENT FOR  
VERTICAL FIN  
MATERIAL: 1/4" PLYWOOD



TEMPLATE MAKE 2  
REINFORCEMENT PLATE - REAR SPAR  
MATERIAL: 1/4" PLYWOOD